

INREACH® MESSENGER PLUS

SOS SATELLITE COMMUNICATOR



PRODUCT OVERVIEW

Say it, show it, share it with the inReach® Messenger Plus SOS satellite communicator. Keep in touch with friends and family beyond mobile service, and exchange two-way text messages with an active subscription¹. Connect your compatible smartphone, and tell them you miss them — or show them the view with voice recordings, photos and group messaging² on the Garmin Messenger™ app. Explore with peace of mind knowing you can trigger an interactive SOS message anytime with your GPS coordinates to Garmin Response, a 24/7-staffed coordination centre for help in an emergency. And, instead of relying on tower-based mobile phone coverage, your messages are sent via the 100% global iridium satellite network. Plus, the durable design withstands extreme temperatures and the battery can last for weeks.



INREACH® MESSENGER PLUS


SOS SATELLITE COMMUNICATOR

KEY FEATURES

EXCHANGE PHOTOS

NEW

Send a selfie or share the sunset over the satellite network, no mobile service required. This requires pairing with the [Garmin Messenger app](#) on your compatible smartphone.



EXCHANGE VOICE MESSAGES

NEW


Tell them you miss them with a 30-second voice message, no mobile coverage needed. This requires pairing with the Garmin Messenger app on your compatible smartphone.



TWO-WAY TEXT MESSAGING

IMPROVED

Exchange text messages with up to 1,600 characters directly on the device. Connect your compatible smartphone to the Garmin Messenger app, and exchange text messages, send emojis, react to messages or start a group chat.



INTERACTIVE SOS

Explore with peace of mind knowing you can send an interactive SOS message anytime to the Garmin ResponseSM centre, our 24/7-staffed international coordination centre for help in an emergency.



INREACH® MESSENGER PLUS

SOS SATELLITE COMMUNICATOR

KEY FEATURES CONTINUED

BATTERY CAN LAST FOR WEEKS

IMPROVED

The internal, rechargeable lithium battery gives you up to 600 hours (25 days) of battery life with a text message or location sent every 10 minutes in low power messaging mode. Get up to 250 photo or voice messages sent on a single battery charge. Depending on usage and tracking modes, the fully charged battery can last for weeks to months - even up to a full year. Visit garmin.com for more battery life specifications based on other mode settings.

GARMIN EXPLORE™ APP

NEW

Plan your trip, see your track on a map, save an activity, and view a course highlight showing how much farther to your destination when paired with the [Garmin Explore app](#) on your compatible smartphone.

RUGGED DESIGN FOR EXTREME TEMPERATURES

inReach was made to operate in extreme hot and cold temperatures. This compact and lightweight device is tough, durable, and water-rated to IPX7.

GLOBAL IRIDIUM SATELLITE NETWORK

Instead of relying on tower-based mobile phone coverage, your messages and SOS alerts are sent via the 100% global iridium satellite network.

GPS ACCURACY

The built-in antenna automatically acquires satellites to update your latitude and longitude position. No need to point your device directly towards the sky to find satellites.

LOCATION SHARING

Share your GPS location and your route anytime with live tracking¹. You can also embed your GPS coordinates with your text, photo or voice messages.

CHECK-IN MESSAGES

Send simple, preset check-in messages that do not count toward your allotted text messages¹.

SEAMLESS CONNECTION

Use Wi-Fi® wireless technology or the mobile connection of your smartphone to send messages. Once you're beyond mobile service or Wi-Fi connection, the device seamlessly switches to the satellite network.

CONTROL REMOTELY

Send and receive text messages or send an interactive SOS message remotely using select compatible Garmin products¹.

INREACH® WEATHER

Get weather reports. You can even request forecasts for your destinations¹.

TRACBACK® ROUTING

Use this feature to navigate back to where you started the same way you came.

SAFETY CHARGING

Dead phone battery? Connect your phone to the device and use the device's battery to charge it.



INREACH® MESSENGER PLUS

SOS SATELLITE COMMUNICATOR

PRODUCT COMPARISON

	INREACH MESSENGER PLUS	INREACH® MESSENGER	INREACH® MINI 2
			
DISPLAY SIZE	1" x 0.43" (2.53 x 1.1 x 2.74 cm)	1" x 0.43" (2.53 x 1.1 x 2.74 cm)	0.9" x 0.9" (23 x 23 mm)
DISPLAY RESOLUTION	160 x 68 pixels	160 x 68 pixels	176 x 176 pixels
BATTERY LIFE	Up to 120 hours with a text message or location sent every 2 minutes in low power messaging mode; up to 70 hours in performance messaging mode. Up to 600 hours with a text message or location sent every 10 minutes in low power messaging mode; up to 110 hours in performance messaging mode. Up to 250 media messages sent on a single battery charge. Up to 1 year when powered off. Note: Battery life estimates are with full sky view and can be significantly impacted by obstructions or tree cover.	Up to 140 hours with a text message or location sent every 2 minutes. Up to 650 hours with a text message or location sent every 10 minutes. Up to 1,100 hours with a text message or location sent every 30 minutes. Up to 1 year when powered off. Note: Battery life estimates are with full sky view and can be significantly impacted by obstructions or tree cover.	Up to 120 hours in high detail activity recording, with a text message or location sent every 2 minutes. Up to 330 hours in standard activity recording, with a text message or location sent every 10 minutes. Up to 720 hours in standard activity recording, with a text message or location sent every 30 minutes. Up to 1 year when powered off. Note: Battery life estimates are with full sky view and can be significantly impacted by obstructions or tree cover.
WATER RATING	IPX7	IPX7	IPX7
PHOTO SHARING	●		
VOICE MESSAGING	●		
TWO-WAY TEXT MESSAGING	Up to 1,600 characters	Up to 160 characters	Up to 160 characters
GARMIN EXPLORE™ MOBILE APP COMPATIBLE	●		
MESSAGE REACTIONS	●		
INTERACTIVE SOS	●	●	●
LOCATION SHARING	●	●	●
INREACH™ REMOTE COMPATIBLE	●	●	●
INREACH™ WEATHER	●	●	●
TRACBACK FEATURE	●	●	●
BREADCRUMB MAP			●

SOS SATELLITE COMMUNICATOR

PRODUCT CONFIGURATIONS

HTS: 8517620000



INCLUDES				COUNTRY OF ORIGIN	
inReach Messenger Plus, USB cable and documentation.				Made in Taiwan. Cable made in China, Taiwan or Philippines.	
DESCRIPTION	SKU	UPC	RRP	TYPE OF DISTRIBUTION	MARKETPLACE BAN
INREACH MESSENGER PLUS SOS satellite communicator with photo and voice messaging	010-02887-00	753759336448	€499.99	Exclusive	Yes

PHYSICAL SPECIFICATIONS

INREACH MESSENGER PLUS	
UNIT DIMENSIONS (WXHXD):	3.1" x 2.5" x 0.9" (7.8 x 6.4 x 2.3 cm)
DISPLAY SIZE (WXH):	1" x 0.43", 1.08" diagonal (2.53 x 1.1 cm 2.74 cm diagonal)
DISPLAY RESOLUTION: (WXH):	160 x 68 pixels
DISPLAY TYPE:	Sunlight-readable, monochrome, transflective memory-in-pixel (MIP)
WEIGHT:	4.1 oz. (117.2 g)
BATTERY TYPE:	Rechargeable internal lithium-ion

PACKAGING SPECIFICATIONS

INREACH MESSENGER PLUS	
GIFT BOX DIMENSIONS (WXHxD):	4.7" x 5.2" x 2.1" (12 x 13.1 x 5.3 cm)
GIFT BOX WEIGHT:	9.4 oz. (266 g)
MASTER CARTON DIMENSIONS (WXHxD):	17.1" x 10" x 15.1" (43.5 x 25.4 x 38.4 cm)
MASTER CARTON WEIGHT:	22.7 lbs (10.3 kg)
MASTER CARTON QUANTITY:	36



INREACH® MESSENGER PLUS

SOS SATELLITE COMMUNICATOR

COMPATIBLE APPS

GARMIN MESSENGER™ APP:



Never lose touch with friends and family. The Garmin Messenger app brings rich network messaging features, including group messaging, to any compatible smartphone.

GARMIN EXPLORE™ APP:



Use the Garmin Explore app to plan your trip, see your track on a map, save an activity, and view a course highlight showing how much farther to your destination.

COMPATIBLE ACCESSORY OVERVIEW

	SKU	UPC	RRP	DESCRIPTION	IMAGE
CRADLE MOUNT AVAILABLE SOON	010-13594-00	753759348366	€14.99	Use the included carabiner and webbing loop to attach your Garmin device to your pack. This non-powered cradle securely attaches to the back of your Garmin Messenger or Garmin Messenger Plus device to make the included Spine Mount 2 an attachment point for your compatible mount.	
USB CABLE TYPE A TO TYPE C	010-13199-00	753759291204	€14.99	Connect this cable to a USB A port to recharge your compatible device and to transfer data to and from your computer.	
USB CABLE TYPE C TO TYPE C	010-13323-00	753759322854	€14.99	Connect this cable to a USB-C port to recharge your compatible device and to transfer data to and from your computer. This cable also pairs with an optional AC adapter (sold separately).	
DUAL PORT USB POWER ADAPTER (USB-A)	010-13023-02	753759280826	€14.99	Use this portable USB power adapter to charge two compatible devices at the same time from any standard wall outlet. This adapter includes two USB ports with 5V/2.4A output power for quick charging, plus a compact, foldable plug so it's easy to travel with.	
FLOTATION LANYARD	010-12525-01	753759177133	€9.99	Keep your device secure and close on hand on the water with this neoprene flotation lanyard, featuring a quick-release connector.	
QUICK RELEASE LANYARD	010-11733-00	753759980283	€14.99	Attach your handheld to this quick-release lanyard and wear it around your neck so you can keep your hands free during your outdoor adventure.	
RETRACTABLE LANYARD	010-10888-00	753759066604	€24.99	Keep your GPS close and secure with this retractable lanyard.	

¹Active satellite subscription required. Some jurisdictions regulate or prohibit the use of satellite communication devices. It is the responsibility of the user to know and follow all applicable laws in the jurisdictions where the device is intended to be used.
²Photo and voice messaging requires use of the Garmin Messenger™ app on your compatible smartphone.

Wi-Fi is a registered trademark of the Wi-Fi Alliance.